

A FEW QUICK STEPS TO DOUBLE CHECK YOUR GARAGE DOOR OPENER

Is there power to the opener?

- Is the wall station next to door coming into the house lit up?
- If not check your circuit breaker and GFI

Do the main lights on the opener flash when you try to close the door?

- This is an indication that the sensing eyes are blocked or misaligned
- Check to see if anything is in the way of the sensing eyes.
- Are the sensing eyes lit up? If there is power one will light up. If they are properly aligned they will both glow steadily.
- You can override the sensing eyes to close your door by holding down the button on the control panel near the door into your home.

My remotes don't work

- Check to see if the lock feature has been engaged. If the wall control is flashing the lock feature needs to be turned off.
- Try reprogramming the remote to your opener, see the user manual that came with your opener for instructions
- Change the battery in the remote. The battery will last for several years with normal operation

My keyless entry pad does not work

- Try reprogramming the remote to your opener, see the user manual that came with your opener for instructions
- Replace the battery, there is a cover on the lower portion of the keypad

My door is making more noise

- Twice a year lubricate the hinges and the roller stems. You can find a spray lubricant engineered for garage doors at most home centers. Do not lubricate the rollers themselves or the track.

Always refer to the user manual that came with your garage door opener. Your garage door is the largest and heaviest moving part in your home, service should be performed by a qualified technician.